



# Dyson Ball Multi Floor Upright Main Filter Replacement

Replace the main filter to get better suction from your vacuum.

Written By: Nicole Abraham



## INTRODUCTION

After multiple uses of your Dyson Multi Floor Upright the filters will begin to wear and become clogged. To get more suction and use out of your vacuum these filters must be replaced every so often.

## Step 1 — Main Filter



- For the main filter, locate the body of the vacuum by looking for the cylinder with the orange top. Use your thumb to press down on the red button towards the back of the orange piece.
- After pressing down on the red button, the body of the vacuum will easily be removed from the vacuum stand.

## Step 2



- Once the main body of the vacuum is removed, locate the clear handle on the top of the body. There is a purple label that says "Filter".
- Lift up the clear handle to reveal the main cylindrical filter. Pull out the purple filter piece to replace.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-19 03:30:17 PM.